




سما رایان صنعت




The screenshot shows the 'Printing Properties' dialog box in the Label Artist software. The dialog is divided into several sections with various settings:


- Paper Size List:** 'User Defined Paper' is selected. The unit is set to 'mm' (value 1). Paper Width is 101.6 mm and Paper Height is 152.4 mm.
- Print Direction:** 'Top to bottom' is selected.
- Print Speed (inch per sec):** 5.0 ips is selected.
- Cut Paper:** 'Disable' is selected.
- Back Feed Option:** 'Enable' is selected.
- Print Density (1~20):** 12 is selected.
- Sensor Type:** 'Gap' is selected with a value of 5.
- Media Type:** 'Direct Thermal' is selected (value 4).
- Gap Length, Off-set Length:** Gap Length is 3 mm and Off-Set Length is 0 mm.
- Multiple columns of labels:** Columns is 1.
- Data compression:** Unchecked.

Annotations in Persian with red arrows point to specific settings:

- 1: واحد اندازه گیری میلیمتر یا اینچ (Unit of measurement in millimeters or inches)
- 2: عرض کامل کاغذ از لبه زرد کفنه زیر لیبل (Full paper width from the bottom yellow edge of the label)
- 3: ارتفاع خالص یک لیبل (Pure height of one label)
- واحد عرض و ارتفاع بر حسب میلیمتر میباشد (Width and height are in millimeters)
- فاصله بین دو لیبل (Distance between two labels)
- فاصله بین دو لیبل (Distance between two labels)
- تعداد ردیفهای افقی (Number of horizontal rows)
- حرارت پرینتر (Printer temperature)
- پایان عملیات (End operation)

This screenshot shows the main interface of the Label Artist software. The central area is a large white rectangle representing the label design space. The software's menu bar (File, Edit, Object, Database, View, Setting, Printer Model, About) and toolbar are visible at the top. A status bar at the bottom indicates 'PortName: <USB001>'. A large watermark 'سما رایان صنعت' is overlaid diagonally across the bottom right of the interface.





The screenshot shows the 'Text Object Properties' dialog box in the Label Artist software. The dialog is divided into several sections:

- Text:** Contains a text input field with 'Text' entered, a 'Link Database' checkbox, and a 'Configuration' button.
- Printer Device Font:** Includes 'Font Faces' (English [24 x 38] (dots)), 'Vertical Multiple' and 'Horizontal Multiple' spinners, 'Use auto-counter' checkbox, and a 'Configuration' button.
- Rotation:** Features radio buttons for 'NoRotation', '90 Degree', '180 Degree', and '270 Degree'.
- Font Style:** Includes radio buttons for 'Normal' and 'Bold', and checkboxes for 'Italic Type', 'Underline Type', and 'Locked'. A note below reads 'ضخیم نمودن فونت نوشته' (thickening the written font).
- Use True Font:** A checked checkbox.
- Windows True Font:** Includes 'Font Faces' (Consolas) and 'Font Size' (15) dropdown menus.
- Buttons:** 'Ok' and 'Cancel' buttons at the bottom.

Persian annotations with arrows point to specific elements:

- An arrow points to the 'Text' input field with the text: 'نوشته مورد نظر را در داخل این قسمت مینویسید.' (Write the desired text in this section).
- An arrow points to the 'Rotation' section with the text: 'چرخش نوشته به صورت‌های مختلف' (Rotation of text in different ways).
- An arrow points to the 'Bold' radio button with the text: 'ضخیم نمودن فونت نوشته' (thickening the written font).
- An arrow points to the 'Font Faces' dropdown in the 'Windows True Font' section with the text: 'نوع فونت نوشته مورد نظر' (Type of the desired written font).
- An arrow points to the 'Ok' button with the text: 'پایان عملیات' (End of operation).

A large watermark 'سما رایان صنعت' is visible in the bottom right corner of the image.

The image shows a screenshot of the Label Artist software interface. The main window displays a label design with the text "تست سما رایان صنعت" (Sama Rayan Sanat Test) and a barcode. A red arrow points to the barcode icon in the top toolbar, labeled "بارکد" (Barcode). A dialog box titled "Barcode Object Properties" is open, showing configuration options for the barcode. The dialog has two tabs: "1D Barcode" and "2D Barcode". Under "Barcode Symbol", "Code39" is selected. The "Rotation" section has "NoRotation" selected. The "HRI (Human Readable Interface)" section has "Bottom of Barcode (Font Size: 1)" selected. The "Barcode Data" section has "1234567890" entered. The "Print as bitmap" checkbox is checked. The "Ok" button is highlighted. Four numbered arrows point to specific elements: 1. "انتخاب نوع بارکد" (Select barcode type) points to the "Barcode Symbol" dropdown. 2. "نمایش بارکد" (Display barcode) points to the "Preview" section. 3. "بارکد مورد نظر وارد نمودن عدد" (Enter the number of the desired barcode) points to the "Barcode Data" input field. 4. "پایان عملیات" (End operation) points to the "Ok" button. A watermark "سما رایان صنعت" is visible in the bottom right corner.

بارکد

تست سما رایان صنعت

انتخاب نوع بارکد ۱

نمایش بارکد ۲

بارکد مورد نظر وارد نمودن عدد ۳

پایان عملیات ۴

چرخش نوشته

Barcode Object Properties

1D Barcode 2D Barcode

Barcode Symbol

Code39

Code128

I2of5

Codabar

Code93

UPC-A

UPC-E

Rotation

NoRotation 90 Degree 180 Degree 270 Degree

HRI (Human Readable Interface)

Bottom of Barcode (Font Size: 1)

Preview

Barcode Data

1234567890

Use auto-counter

Change Setting

Print as bitmap

Locked

Ok Cancel

سما رایان صنعت

